









# TELESCOPIC HANDLER HAND SIGNALS CHART

 <p><b>Emergency Stop</b> With both arms extended, &amp; hands open downward, move arms back and forth.</p>	 <p><b>Stop</b> With either arm extended, &amp; hand open downward, move arm back and forth.</p>	 <p><b>Raise Boom</b> With either arm extended, fingers closed, point thumb upward.</p>	 <p><b>Lower Boom</b> With either arm extended, fingers closed, point thumb downward.</p>
 <p><b>Extend Telescopic Boom</b> With both hands clenched, point thumbs outward.</p>	 <p><b>Retract Telescopic Boom</b> With both hands clenched, point thumbs inward.</p>	 <p><b>Tilt Forks Up</b> With one arm held at side, extend other arm upward at about 45-deg angle.</p>	 <p><b>Tilt Forks Down</b> With one arm held at side, extend other arm downward at about 45-deg angle.</p>



9601 Granger Road Cleveland, OH 44125  
 Tele: 216-587-0400 Fax: 216-587-4669